

## **Pre-installation Checklist**

| _     |          |            |         |
|-------|----------|------------|---------|
|       | 1.5.000  | tou incto  |         |
|       |          | TOT IIISIA |         |
| COLIG | 11616113 | for instal | nation. |

| 1. The ambient temperature:5 - 35 $^{\circ}$ C, and the relative hun | nidity:≤ 85%. |
|--|---------------|
|--|---------------|

- 2. The laboratory should be free of violent vibration, airflow, strong electromagnetism and corrosive gases.
- 3. Equip the laboratory with proper work surface: 700mm (W)×2000 mm(L)×600mm(H).
- 4. Equip the laboratory with stable power supply of 220 V ± 22 V / 50 ± 1 Hz (grounded well). Heating power ≤ 1.5 kW.

Reserve locations for one air switch and one three-core socket.

## **Preparation:**

- 1. Dryer: Silica gel, 1 Bottle.
- 2. Absorbent cotton (medical).
- 3. Standard coal samples in which all kinds of moisture content are contained.
- 4. Prepare one desicator.